

5

10

FIG. 1

15 1) PREPARE DECONTAMINATED MANURE → MANURE  
TREATMENT

20

2) OBTAIN HUMIC ACID AND N-P-K INGR. → LAB Q.C.

25

3) PREPARE BACILLUS SPORES → FERMENTATION

30

4) MIX DRY INGREDIENTS → DECONTAMINATED MANURE  
+ HUMIC ACID + N-P-K

35

5) GRIND DRY INGREDIENTS → 100 – 150 MESH

6) SPRAY ON BACILLUS SPORES → GRANULATE

40

7) PRODUCE PRILLED PRODUCT → – ROTATING DRIER –  
COOL – SCREEN – BAG

10038676-133401




FIG. 2